

Minibake Convection Oven

EN

Operation and Maintenance Manual (for Supermarkets)



Product Version

- Fan assisted oven
- 3-tray or 4-tray capacity (depending on model)
- Bake Zone compatible
- UK specifications

Р	ro	du	ct	Se	rial	N	um	ber
---	----	----	----	----	------	---	----	-----

Product Model Codes

FG140-A03L

FG140-A03R

FG140-A04L

FG140-A04R

Manual Revisions

Revision	Publication Date	Author	Description
A25	27-MAY-2025	CD	First edition.
B25	05-JUN-2025	CD	Added Cleaning chapter.
C25	08-JUN-2025	CD	Updated front page to include oven model codes.
G25			Corrected oven model code in the Monthly Cleaning section.
D25	12-JUN -2025	CD	Corrections to tray and oven dimensions. Additional specifications.
E25	30-JUN-2025	CD	Total Power speficiation changed to 2.9 kW.
F25	26-JUL-2025	CD	Changed (Abridged) to (for Supermarkets) throughout manual.

MONO Rev. F25 (July 2025)

Thank you

Thank you for purchasing MONO's Minibake Oven.

Before using your new oven for the very first time, please read and familiarise yourself with the contents of this User Manual and keep it handy for future reference.

If you have any queries regarding your oven, please contact MONO Equipment directly:

- +44 (0)1792 561234
- sales@monoequip.com
- spares@monoequip.com
- techsupport@monoequip.com

We wish you the very best of success with your new professional Minibake Oven.

Happy baking!

The MONO Team

Attention



NOTE


If the oven fails to heat up when first connected to a power supply or during use at any time, press the **reset button** located underneath the oven.



CAUTION

Two persons are required to lift this oven safely.

UNDERSIDE VIEW



A. Reset button location underneath the oven

Safety Symbols

The following safety symbols are used throughout this user manual (available electronically at **MonoEquip.com**). Before using your new equipment, read the user manual carefully and pay special attention to information marked with the following symbols.



DANGER

Indicates an immediate hazard with a high risk, which if not avoided, will result in death or serious physical injury.



WARNING

Indicates a potential hazard with a medium risk, which if not avoided, could result in death or serious physical injury.



CAUTION

Indicates a hazard with a low risk, which if not avoided, could result in minor or moderate physical injury.

Electrical Safety Notice

Advice regarding supplementary electrical protection

Commercial bakeries, kitchens and food service areas are environments where electrical appliances may be located close to liquids, or operate in and around damp conditions, or where restricted movement for installation and service is evident.

The installation and periodic inspection of the appliance should only be undertaken by a qualified, skilled and competent electrician, and connected to the correct supply suitable for the load as stipulated by the appliance data label.

The electrical installation and connections should meet the necessary requirements of the local electrical wiring regulations and any electrical safety guidelines.

We recommend:

Supplementary electrical protection with the use of a residual current device (RCD)

Your attention is drawn to: BS 7671:2018 - Guidance Note 8 - 8.13: Other locations of increased risk

It is recognised that there may be locations of increased risk of electrical shock other than those specifically addressed in Part 7 of BS 7671. Examples of such locations could include laundries where there are washing and drying machines in close proximity, and water is present, and commercial kitchens with stainless steel units, where once again, water is present. Where, because of the perception of additional risks being likely, the installation designer decides that an installation or location warrants further protective measures, the options available includes:

 Automatic Disconnection of Supply (ADS) by means of a residual current device having a residual operating current not exceeding 30 mA.



WARNING

- The supply to this machine must be protected by a 30mA-rated Type 'A' Residual Current Device (RCD).
- Before installation, it is recommended that the power socket is tested by a qualified electrician for electrical safety.

General Notices



CAUTION

- Users with Implantable Cardioverter Defibrillators and Pacemakers
 - Several common types of devices and machinery may interfere with implantable cardioverter defibrillators (ICDs) and pacemakers, including mobile phones, headphones, radios, machinery, and magnets.
 - The electromagnetic waves generated by these devices can keep your ICD or pacemaker from functioning correctly. Try to avoid them, or at least minimise your exposure to them.
 - Your healthcare professional can advise you about specific devices and machinery to avoid.



NOTICES

Warranty information

- Ambient working temperatures for electrical components, such as solenoid switches, circuit breakers and motors, should not exceed 40 °C (115 °F).
 Manufacturers of these, and other electrical components, advise that any ambient temperature above this affects the functionality of the components. Any related guarantees become void.
- It is the owners' responsibility to ensure adequate ventilation is provided. Any component malfunctioning during the guarantee period found to have been subjected to excessive humidity or ambient working temperatures is not covered by the component manufacturer's or MONO Equipment's product warranty.
- Failure to adhere to the cleaning and maintenance instructions detailed in this User Manual also could affect the warranty of this machine.
- Visit the MONO Parts and Labour Warranty page for further information.
- Continuous improvements
 - As it is our policy to improve our machines continuously, we reserve the right to change specifications without prior notice.
- Engineers/Electricians-only sections of the User Manual
 - Technical sections of this User Manual are for suitably qualified and experienced persons only. Customers must never make any modifications or repairs to MONO's machines.

Declaration of Conformity Certificate



Declaration of Conformity



We the manufacturer:

MONO EQUIPMENT

Queensway, Swansea West Industrial Park, Swansea SA5 4EB UK Machine:

FG Code:

Serial No:

Hereby declare that this machine conforms with and complies with the following directives:

- → The Machine Directive 2006/42/EC
- → The Low Voltage Directive 2014/35/EC
- → The Electromagnetic Compatibility Directive 2014/30/EU Incorporating Standards EN 55014-1:2017/A11:2022 & EN 55014-2:1997+A1:2001+A2:2008
- → The General Safety of Machinery and Food Processing Standards
- → Materials and Articles Intended to Come into Contact with Food Regulation (EC) No. 1935/2004
- → Good Manufacturing Practices (GMP) for Materials Intended to Come into Contact with Food
 - Regulation (EC) No. 2023/2006

A technical construction file for this machine is retained at MONO Equipment

MONO Equipment is a business name of AFE Group Ltd Registered in England No. 3872673

VAT Registration No. 923428136

Registered office: Unit 35, Bryggen Road, North Lynn Industrial Estate, Kings Lynn Norfolk, PE30 2HZ

Mr Craig Petherbridge Quality & Compliance Manager

Mr Alex Davies Engineering Manager

QD 001 Dated 01/11/2022

Contents

	Thank	you	ii		
	Attenti	Attention			
	Safety	Symbols	iv		
	Electri	cal Safety Notice	v		
	Genera	al Notices	vi		
	Declar	ation of Conformity Certificate	vii		
Chapter: 1	Introd	luction			
	1.1	The MONO Minibake Oven	1		
Chapter: 2	Safety	/			
	2.1	General safety	2		
	2.2	Oven safety	2		
	2.3	Isolating the oven from the electrical supply	3		
Chapter: 3	Instal	lation			
	3.1	Safety messages	4		
	3.2	Installation guidelines	4		
		Important information about installing the oven	4		
Chapter: 4	Opera	ntion			
	4.1	Operating controls	5		
	4.2	How to bake using preset programs	5		

Chapter: 5	Cleaning				
	5.1	Cleaning guide for the Minibake Oven	7		
	5.2	Safety messages	7		
	5.3	Daily cleaning	7		
		General cleaning	7		
		Checking and cleaning the door seal	8		
	5.4	Weekly cleaning	8		
		General cleaningGlass-door cleaning			
	5.5	Monthly cleaning	10		
		Cleaning the baking chamber	10		
Chapter: 6	Maintenance				
	6.1	Safety messages	12		
	6.2	General maintenance	12		
Chapter: 7	Servi	ce			
	7.1	Contact information for customer services	13		
	7.2	Further information	13		
	7.3	Environmental disposal	13		
Appendix: A	Dime	nsional Drawings	14		
Appendix: B	Specifications				
Appendix: C	Spares				
Appendix: D	Electrical Information18				

Page Left Blank Intentionally

1. Introduction

1.1. The MONO Minibake Oven

MONO's Minibake Convection Oven is a compact, electric oven with a capacity for three or four 455mm x 325mm baking trays (depending on the model). The oven is robustly made of stainless steel, allowing the unit to be easily cleaned. It has generous amounts of insulation for superb heat retention and energy-saving benefits.

Figure 1.1: Minibake oven features



- A. Control panel
- B. Tray runners
- C. Easy-to-use door handle (Pull to open door, push to close door
- D. Fan for convected baking
- E. Glass-fronted door with vents

2. Safety

2.1. General safety



CAUTION

Magnets information

- Magnetic fields in magnets, used in devices and machinery, can inhibit
 pulse generators for Implantable Cardioverter Defibrillators (ICDs) and
 pacemakers. Magnets can activate a switch prohibiting the ICD from
 delivering vital signals such as lifesaving shocks.
- If you have an ICD or pacemaker, avoiding close or prolonged contact
 with magnets or their magnetic fields is advisable. Keep magnets at
 least six inches from where your device is implanted. If you feel any
 interference in any way, immediately move away from the source.

2.2. Oven safety

Only fully trained and authorised persons are permitted to do any work on the oven. Qualified electricians must carry out all electrical repairs and maintenance. Always disconnect or completely isolate the power supply before starting any maintenance or cleaning work on the oven.

A responsible Bakery Manager or Supervisor must carry out daily safety checks. Bakery staff must not, under any circumstances, remove covers or panels to access any internal parts of the oven.



WARNING

- Before using the oven:
 - Check that all covers, panels, and cabling are secure.
 - Visually examine the oven for obvious damage or signs of tampering.
- If the oven is damaged, malfunctioning, or missing parts:
 - Stop using it. Do not attempt any repairs to the oven.
 - Contact MONO Equipment for technical assistance.
- Never operate the oven with any covers or panels removed.
- All utility connections to the oven must comply with the statuary requirements of the country.
- Ensure this user manual is read thoroughly before operating the oven.
 Operate and maintain the oven only as described in this user manual.



WARNING

- An electrical socket must be protected by a 30mA-rated Type 'A' Residual Current Device (RCD) before installation and commissioning of the oven.
- There should always be a local disconnection switch for any person to isolate the electrical power in an emergency. The disconnection switch must be visible, labelled as an emergency shutdown device, and easily accessible.
- Check the electrical requirements on the oven's information plate before
 plugging in the power cable and turning the power on for the first time.
 Contact MONO Equipment if the electrical ratings are incorrect for your site.
- Before installation, it is recommended that a qualified and competent electrician first tests the electrical outlet (power socket) for electrical safety.
- Always ensure your hands are dry before touching any electrical components, including cables, switches, and plugs.



CAUTION

- Be aware of hot surfaces:
 - Do not touch the oven door with bare skin.
 - Always use oven gloves when loading or unloading the oven.
 - Allow time for the oven to cool completely before cleaning it.
 - While baking (and for some time after use), touching the oven door or the surrounding panels is not advisable because of conducted heat.
- When removing products from the oven, ensure the trays are put in a safe cooling area.
- Fully train operatives before they use the machine. Anyone undergoing training must be under direct supervision of someone experienced.
- Ensure there are no trip hazards around the oven, e.g. trailing cables.
- Check that the floor around the oven is not slippery, e.g. no liquid spills.
- Do not store items on top of or behind the oven.
- Only use the oven for baking bread, pastries, and cakes. Contact MONO Equipment for other product-baking machines.
- No unauthorised modifications to the oven are permitted.

2.3. Isolating the oven from the electrical supply

To stop the oven in an emergency:

- Switch off the electricity at the wall-mounted isolator switch (if fitted), or
- Unplug the oven from the electrical outlet.

3. Installation

3.1. Safety messages



WARNING

- An electrical socket must be protected by a 30mA-rated Type 'A' Residual Current Device (RCD) before installation and commissioning of the oven.
- There should always be a local disconnection switch for any person to isolate the electrical power in an emergency. The disconnection switch must be visible, labelled as an emergency shutdown device, and easily accessible.
- Check the electrical requirements on the oven's information plate before
 plugging in the power cable and turning the power on for the first time.
 Contact MONO Equipment if the electrical ratings are incorrect for your site.
- Before installation, it is recommended that a qualified and competent electrician first tests the electrical outlet (power socket) for electrical safety.
- Always ensure your hands are dry before touching any electrical components, including cables, switches, and plugs.



CAUTION

This equipment is too heavy for a single person to lift.

3.2. Installation guidelines


Important information about installing the oven

- Ensure the oven base is level or on a level working height surface capable of supporting 50kg.
- An operational clearance of 50mm (2 inches) is required at the rear and sides of the oven, and 250mm (10 inches) topside clearance to allow air to circulate.
- Before first use, MONO recommends that you thoroughly wipe the inside surfaces of the oven and all accessories with a clean cloth soaked in warm soapy water. Although the utmost care is taken during assembly and delivery, there is a possibility of residue contaminating your first bake unless it is done.

4. Operation

4.1. Operating controls

Figure 4.1: Front panel controls



- A. START/STOP BAKE button
- C. UP/DOWN ARROW button
- B. Main display window
- D. Program display window

4.2. How to bake using preset programs

The following instructions guide you through using the oven.

- 1. Connect power to the oven.
 - Observe the main display window showing OFF after connecting the power.
- 2. Press the **START BAKE** button.
 - Observe the main display flashing HTG to indicate that the oven is heating up.
- 3. Use the UP ARROW and DOWN ARROW buttons to select the program number required.
 - Observe a temperature in the main display window for two seconds before the flashing HTG re-appears. The oven continues to heat up.
- **4.** When the oven reaches the temperature required:
 - The main display window changes to show RDY.
 - b. An audible short-beep sound is heard.
- 5. Load the oven with your trays of product.
- 6. Press the **START BAKE** button.
 - Observe a baking countdown in the main display window.
- 7. At the end of the bake:
 - a. An audible continuous-beep sound is heard.
 - b. The oven displays **END** and shuts down after 10 seconds.
- 8. To start the oven again, open the door and then close it.

- **9.** To turn off the oven, hold the **STOP** button for 10 seconds.
 - Observe the main display changing to **OFF**, and the oven will then shut down.

5. Cleaning

5.1. Cleaning guide for the Minibake Oven

Regular cleaning and maintenance of an appliance is essential for optimal performance and longevity. Therefore, it is important to follow a manufacturer's recommended cleaning instructions.

Follow our simple daily, weekly, and monthly cleaning guidelines to ensure your MONO Minibake Oven functions correctly and maintains its durability.

5.2. Safety messages



WARNING

- Ensure the oven is switched off at the mains power supply and has been entirely cooled before undertaking any cleaning tasks.
- Pay particular attention to ensuring excess water is not applied around the area of the electrical panels.



WARNING

Do not remove the rear panelling inside the oven. It provides access to the fan assembly, which is not safety-interlocked and could cause serious injury.



CAUTION

- Use an approved chloride-free cleaning fluid to clean the oven daily.
- Never use aggressive chemicals, such as solvents and thinners.
- Take care to ensure cleaning liquid does not enter the control panel or any of the other access covers/panels.
- Never spray the oven with water (or any kind of liquid) using a hose or pressure washer. Never use compressed-air jets on the oven.

5.3. Daily cleaning

Before undertaking these tasks, ensure the main power supply to the oven is switched off and that the oven has been allowed to cool for several hours.

General cleaning

- 1. Brush any debris out of the oven after it has cooled.
- **2.** Wipe the oven's front and sides with a damp cloth.
- 3. Spot clean the outside with a damp cloth soaked in a solution of mild detergent and hot water.
- **4.** For stubborn stains, use a proprietary stainless steel cleaner on the outer surfaces of the oven.
 - A specially designed cleaning agent can dissolve any fat or grease deposits.
 - Never use steel wool or other abrasive scourers to clean the oven's surfaces.

Checking and cleaning the door seal

The door seal is a crucial part of your convection oven and is prone to wear. Animal fats, grease and caustic cleaning agents attack and weaken the seal material, resulting in an accelerated wear rate. A door seal must be cleaned regularly to help prolong its life and maintain its effectiveness.

- 1. Clean the seal every day using a mild grease solvent.
- 2. When clean, use fresh water to remove any remaining cleaning agent.

To help prolong the life of your oven's door seal, we also recommend the following:

- Leave the oven door open overnight to allow the seal to relax.
- Keep the oven door open when the oven is not in use.
- Regularly inspect the seal for signs of deterioration or damage, and replace it promptly to prevent steam or heat from escaping from the oven chamber.

5.4. Weekly cleaning

Before undertaking these tasks, ensure the main power supply to the oven is switched off and that the oven has been allowed to cool for several hours.

General cleaning

- 1. Complete the daily cleaning tasks.
- 2. Clean any burnt-on debris using a proprietary oven cleaner.
 - Carefully follow the oven cleaner manufacturer's instructions.
 - Do not allow the oven cleaner to come into contact with the control panel.

NOTE

Using excessive water can eventually cause the metalwork to rust.



Glass-door cleaning

Context: The door consists of two parts:

- An outer fixed glass panel.
- An inner glass panel that opens for easy cleaning.
- 1. Remove the screws using a slotted screwdriver (Figure 5.1).
- 2. Open the inner glass panel (Figure 5.2).
- 3. Clean the door glass with a soft, damp cloth.
- 4. For stubborn stains, use a proprietary stainless steel cleaner on the outer surfaces of the oven.
 - A specially designed cleaning agent can dissolve any fat or grease deposits.
 - Never use steel wool or other abrasive scourers to clean the oven's surfaces.
- 5. Re-secure the inner glass with the screws after you have finished cleaning.

Figure 5.1: Location of the two screws for releasing the inner glass




Figure 5.2: Inner glass panel moved away from the door



5.5. Monthly cleaning

Before undertaking these tasks, ensure the main power supply to the oven is switched off and that the oven has been allowed to cool for several hours.

Cleaning the baking chamber

Instructions for models FG140-A03L, FG140-A03R, FG140-A04L, and FG140-A04R

- 1. Remove the central fixing bolt from the front edge of the tray runner using an M6 (10mm) spanner (Figure 5.3).
 - Put aside the bolt for safekeeping.
- 2. Lift the tray runner sheet gently upwards so that the locating tabs at the back of the tray runner disengages from the back panel (Figure 5.4).
- 3. Pull the tray runner towards you to remove it from oven.
- 4. Repeat steps 2 and 3 for the other tray runner on the opposite side.
- 5. Clean the oven chamber and tray runners with a proprietary cleaning agent.
- **6.** When clean, use fresh water to rinse away any remaining cleaning agent.
- **7.** Replace the two tray runners, ensuring the tabs at the back of the sheets are inserted into the corresponding slots at the back of the oven.
- **8.** Clip both tray runners back in place and bolt them to the oven using the bolts removed during step **1**, ensuring the bolts are tightened to secure the tray runners correctly.

Figure 5.3: Unlocking the tray runners



Figure 5.4: Positions of locating tabs



6. Maintenance

6.1. Safety messages



WARNING

 Always disconnect or isolate the electrical supply before starting any maintenance work on the oven.



WARNING

- The Minibake Oven must be maintained at regular intervals. The frequency of maintenance will depend upon your specific use and location. The maximum service interval should be 12 months.
- Service and maintenance should only be undertaken by suitably qualified and experienced persons.
- You must immediately report any damage or defect arising with the appliance.
- Unsafe equipment is dangerous. Do not use the appliance. Isolate the electrical supply and contact MONO Equipment or your appointed service agent.

6.2. General maintenance

The following general maintenance is recommended:

- Check for any visible damage or signs of tampering.
 - Do not use the machine if it is clearly damaged, i.e. frayed or bare wires are visible.
 - Report the damage but do not attempt to make any repairs yourself.
- Follow the cleaning instructions meticulously.
- There is no special maintenance required.

7. Service

If a fault arises, please do not hesitate to contact MONO Equipment's Service and Spares department. Be prepared to provide the Serial Number from the machine's information plate or the front page of this User Manual in all communications.

7.1. Contact information for customer services

MONO Equipment Limited

Queensway Swansea West Industrial Park Swansea SA5 4EB United Kingdom www.monoequip.com

Contacts

spares@monoequip.com +44 (0)1792 564039

techsupport@monoequip.com +44 (0)1792 564041

service@monoequip.com +44 (0)1792 564048

Switchboard +44 (0)1792 561234

7.2. Further information

Visit **MonoEquip.com** the for the latest versions of this user manual. Also find up-to-date information about all MONO's products.


7.3. Environmental disposal


Dispose of the machinery with care when it comes to the end of its working life. Use the most environmentally friendly manner possible by recycling or other means of disposal which complies with local regulations. Only dispose of the machine safely and legally. The Environmental Protection Act 1990 applies in the United Kingdom.


A. Dimensional Drawings

A.1 Minibake Oven dimensional drawings

Figure A.1: Overall dimensions of the oven







Dimensions are in mm (inches).

B. Specifications

B.1 Electrical specifications

Total power: 2.9 kW

Electrical supply: 230V, single-phase, 50Hz, fused at 13A

<u>A</u>

An electrical socket must be protected by a 30mA-rated Type 'A' Residual Current Device (RCD) before installation and commissioning of the oven.

Supply cable: 2 metres of cable supplied

B.2 Mechanical specifications

Height: 600 mm

Depth, door closed

(including handle and exhaust) 719 mm

Depth, door open:

(including handle and exhaust) 1244 mm

Width: 610 mm

Weight: To be advised

Tray capacity: 3 or 4 (depending on model)

Tray size: 455 mm x 325 mm

Height between trays: 80 mm (3-tray model)

67 mm (4-tray model)

B.3 Environmental specifications

Noise level: Less than 85 dB

B.4 Functional specifications

Maximum bake 250 °C temperature:

15 MONO Rev. F25 (July 2025)

C. Spares

C.1 Electrical parts list

24V power supply unit	B801-93-005
Heater relay	B723-37-001
Fan forward relay	B723-37-021
Fan reverse relay	B723-37-021
Light relay	B723-37-021
Overheat thermostat	B888-30-014
Oven controller printed circuit board (PCB)	B705-97-025
Fan unit	B720-74-004
Heating element, 230V	B854-04-119
Control fuse	B842-85-039
Controller fuse	B842-85-013
Interior LED light fuse	B842-85-030
Terminal blocks (blue)	B852-50-012
Terminal blocks (beige)	B852-50-013
Terminal blocks (fused)	B852-39-004
Terminal blocks (earth)	B852-86-005
Door switch assembly	B842-07-037
Thermocouple	B873-95-002
13 Amp plug	B835-25-002
LED strip	B855-94-015
LED door connectors (male)	B855-94-016
LED door connectors (female)	B855-94-017
LED power supply	To be advised

C.2 Non-electrical parts list

Three-tray runner, right-hand (R/H)	140-01-00005
Three-tray runner, left-hand (L/H)	140-01-00006
Four-tray runner, R/H	140-01-00015
Four-tray runner, L/H	140-01-00017
Inner door assembly	140-03-00014

Door seal	140-03-00020
Roller catch body (door)	A900-01-384
Roller catch stud (oven)	A900-01-383
Door hinge bearing	A900-06-347
Glass-retaining screw	138-03-05200
Outer door glass	140-03-00005

17 MONO Rev. F25 (July 2025)

D. Electrical Information

D.1 Electrical drawings

Figure D.1: Three-tray power circuit drawing M140E25-00001




Figure D.2: Three-tray control circuit drawing M140E25-00002





Figure D.3: Control and power circuit for 220V/240V 1-phase 2-way fan drawing M140E25-00003



Page Left Blank Intentionally

Page Left Blank Intentionally

MONO Equipment is the leading designer and manufacturer of bakery equipment in the United Kingdom. This proud heritage of British craftmanship, combined with a reputation for creating high-quality, innovative products, can be traced back to its origins in 1947.

All our bakery equipment is manufactured to the most stringent NQA ISO9001:2015 & NQA ISO14001:2015 standards and is crafted using the very latest, cutting-edge technology combined with the time-honoured skills of the master craftsman.

MONO Equipment truly excels in providing tailor-made solutions to a diverse range of clients, from the small independent artisan baker to the large retail chains found on every high street and in every out-of-town shopping centre. We can supply everything from a simple Food-2-Go cafe oven to the entire list of bakery equipment needed to set up a full scratch bakery.



MONO Equipment Limited

Queensway Swansea West Industrial Park Swansea SA5 4EB

Tel: +44 (0)1792 561 234 (Switchboard) Tel: +44 (0)1792 564 000 (UK Sales)

Tel: +44 (0)1792 564 004 (International Sales)

Tel: +44 (0)1792 564 048 / +44 (0)1792 564 049 (Spares)

Fax: +44 (0)1792 561 016

Email: sales@monoequip.com web: www.monoequip.com



Scan using your smart phone to view our website









