



PARTS LIST		
ITEM	PART NUMBER	DESCRIPTION
1	150-03-02100	DOOR BOLT
2	160-06-08500	HINGE
3	166-13-00022	P' SEAL RETAINING STRIP LH (INNER)
4	166-13-00023	P SEAL RETAINING STRIP - TOP
5	166-13-00024	P' SEAL RETAINING STRIP (INNER)
6	166-13-00025	P' SEAL RETAINING STRIP RH (INNER)
7	166-13-00027	BOTTOM SEAL RAIL
8	166-13-00028	DOOR BOTTOM SEAL FIXED PLATE
9	166-13-00029	P SEAL RETAINING STRIP - LH
10	166-13-00030	P SEAL RETAINING STRIP - RH
11	166-13-00034	DOOR BOTTOM SEAL RETAINING PLATE
12	166-13-00045	CABLE GUIDE PLATE BOTTOM
13	166-13-00046	CABLE GUIDE PLATE MID
14	166-13-00047	CABLE GUIDE ASSY - RH DOOR
15	166-13-00057	LED LIGHT UNIT
16	166-13-00059	P SEAL
17	166-13-00068	RACK OVEN HANDLE


 QUEENSWAY
 SWANSEA WEST IND. PARK
 SWANSEA SA5 4EB
 TEL 01792 561234
 FAX 01792 561016

RACK OVEN (FG166) DOOR ASSEMBLY RH