



PARTS LIST			
ITEM	PART NUMBER	DESCRIPTION	SPARES NUMBER
1	200-02-00017	BUTTON	
2	481-03-00001	FRONT SEALING PAD	
3	481-03-00002	SEALING PAD SIDE	
4	482-02-00017	SPRING BRKT	
5	482-02-00019	LOADING PLATFORM	
6	482-02-00025	GUIDE TUBE ASSY	
8	482-03-00010	SWITCH ACTUATOR	
9	482-04-00006	ROBIN SEALING ARM ASSEMBLY	
10	482-04-00007	PIVOT BAR	
11	482-04-00008	PIVOT SPACER SMALL	
12	482-04-00009	PIVOT SPACER LARGE	
13	482-04-00010	SPRING PLATE	
14	482-04-00013	SPRING TENSIONING BOLT	
15	482-05-00008	FLOATING MANDREL BAR	
17	A900-06-302	M10 ROD BEARING	
18	A900-18-098	FAST FITTING FOOT	
19	A900-19-098	EXTENSION SPRING 127mm FREE LENGTH	
20	A900-33-011	ROLLER	
21	B803-08-002	DANFOSS CONTACTOR - TYPE C116 037H0041.31	
22	B811-49-005	SNAP BUSHING-SB-625-500-N'2830	
24	B842-07-026	MICROSWITCH C/W BLACK ACTUATOR	
26	B842-50-011	FUSEHOLDER (DIN)	
27	B853-31-002	TRANSFORMER - TYPE W145A	
28	B878-91-001	TEMPERATURE SIMULATOR - TYPE SM200 DUAL AC	
29	B883-09-008	IP67 INSPECTION WINDOW	


 QUEENSWAY
 SWANSEA WEST IND. PARK
 SWANSEA SA5 4EB
 TEL 01792 561234
 FAX 01792 561016

Robin L-Sealer Main Assembly